


AMIGA 500 - SWITCHLESS BOOT DRIVE SELECTOR

Installation Instructions



- Open the Amiga Case.
- Carefully remove Even CIA (b).
- Seat the chip in the boot selector making sure the orientation is correct.
- Seat the boot selector in the empty CIA slot, again making sure the orientation is correct.
- Reassemble the Amiga

To Operate

While using "3 RESET BOOT DRIVE SELECTOR", if you want to toggle your floppy drives (DF:0 <> DF:1) you just need to press Reset keys 3 times. (Reset Keys are: CTRL and the two Amiga keys together)